

[→ Product Website](#)[→ Experience in AR](#)

Energy-saving, ergonomic and reliable, the EV2781 shines with its picture quality. It receives the image signal, audio and USB data via its USB-C interface. The 70 W power delivery via USB-C is particularly practical. Here, notebooks can be connected and powered quickly and conveniently with just one cable. DisplayPort and HDMI inputs as well as four USB downstream ports complete the extensive connectivity options. This convenient multi-purpose connectivity simplifies a quick move when users use different workstations in the office or switch between office and home office. A picture-by-picture mode even allows simultaneous display of different signal sources. Useful when two computers are connected. The IPS LCD of the EV2781 offers a resolution of 2560 x 1440 pixels - this corresponds to a pixel density of 109 ppi for optimal readability. Matte anti-glare and Auto EcoView brightness control create a glare-free view, while sophisticated hybrid LCD backlight control ensures flicker-free viewing. The EV2781 can be rotated, swivelled and tilted in the way that is most comfortable for the back, neck and sitting posture. Its virtually bezel-less design provides a refined aesthetic. Controls, brightness sensor and speakers are integrated into the slim front bezel.

- ✓ 27" monitor with 2560 x 1440 pixels and fine 109 ppi resolution for excellent readability
- ✓ Ideal connectivity thanks to USB-C interface with DisplayPort signal channel and power supply up to 70 watts
- ✓ Only 1 mm housing frame: super-compact and ultrachic design
- ✓ Flicker-free image reproduction through hybrid control of image brightness
- ✓ Auto EcoView and EcoView Optimizer for maximum energy savings and ideal ergonomics
- ✓ Optimum anti-reflective coating and flexible positioning
- ✓ USB hub version 3.1 with one USB-C upstream and four USB-A downstream ports
- ✓ Signal inputs: USB-C (DisplayPort Alt Mode), DisplayPort, HDMI
- ✓ Demonstrably environmentally and socially responsible production
- ✓ 5-year warranty for highest investment security

Technical Data

GENERAL		FEATURES & OPERATION	
Item no.	EV2781-BK EV2781-WT	USB-C docking	✓
Case color	Black White	Preset color/greyscale modes	2x manual memory locations, sRGB, Paper, Movie, DICOM
Areas of application	Office	DICOM tone curve	✓
Product line	FlexScan	Auto EcoView	✓
Areas of application	Large and medium-sized companies, Private user & small business, Home Office, CAD, Finance, Control rooms	EcoView Index	✓
Specific system requirements	None, compatible with most computers and operating systems including macOS and Windows	EcoView Optimizer	✓
EAN	4995047063438 4995047063445	Overdrive	✓
		No flickering	✓
		HDCP Decoder	✓
		Automatic signal input recognition	✓
		Imagen por imagen	✓
		Built-in speakers	✓
		On-screen menu languages	de, en, fr, es, it, se
		Adjustment options	Color Mode, Brightness, Contrast, Color temperature /White point, Gamma, Overdrive, Colour tone, Color saturation, Picture-by-Picture, Resolution, Scaling, OSD language, Signal input, All EcoView functions, Volume
		Button Guide	✓
		Integrated power unit	✓
SCREEN		ELECTRICAL DATA	
Screen size [in inches]	27	Frequency	USB-C: 31-89 kHz/59-61 Hz; DisplayPort: 31-89 kHz/59-61 Hz; HDMI: 31-89 kHz/ 49-51 Hz/59-61 Hz
Screen size [in cm]	68.5	Power consumption (typical) [in watts]	18
Format	16:9	Maximum Power Consumption [in watts]	153 (at maximum brightness and operation of all signal and USB ports as well as full charging power)
Viewable image size (width x height) [in mm]	597 x 336	Max. Power consumption in stand-by mode [in watts]	0.5
Ideal and recommended resolution	2560 x 1440	Power consumption with power switch off [in watts]	0
Pixel pitch [in mm]	0.233 x 0.233	Energy efficiency class	D
Pixel density [in ppi]	109	Energy consumption/1000h [in kWh]	17
Supported resolutions	2560 x 1440, 1920 x 1200, 1920 x 1080 (Full HD), 1680 x 1050, 1600 x 1200, 1280 x 1024, 1024 x 768, 800 x 600, 720 x 400, 640 x 480	Power supply	AC 100-120 V / 200-240 V, 50/60 Hz
Panel technology	IPS	Max. USB-C Power Delivery [in Watt]	70
Max. viewing angle horizontal	178	Power management	✓
Max. viewing angle vertical	178		
Number of colors or greyscale	16.7 million colors (DisplayPort, 8 Bit), 16.7 million colors (HDMI, 8 Bit), 16.7 million colors (USB-C, 8 Bit)		
Color palette/look-up table	More than 1.06 billion color tones /14-bit		
Max. color space (typical)	sRGB		
Max. brightness (typical) [in cd/m²]	350		
Max. dark room contrast (typical)	1000:1		
Response time grey-grey alternation (typical) [in ms]	5		
Backlight	LED		
CONNECTIONS			
Signal inputs	USB-C (DisplayPort Alt Mode, HDCP 1.3), DisplayPort (HDCP 1.3), HDMI (HDCP 1.4)		
USB specification	USB 5Gbps (USB 3)		
USB upstream ports	1 x type C (DisplayPort Alt Mode, 70 W max.)		
USB downstream ports	4x type A		
Graphic signal	USB-C, DisplayPort, HDMI (RGB, YUV)		
Audio input	USB-C, DisplayPort, HDMI		
Audio / headphone output	3.5 mm stereo jack		

DIMENSIONS & WEIGHT

Dimensions (incl. stand) (width x height x depth) [in mm]	611 x (369 - 545) x 230
Weight (incl. stand) [in kg]	8.5
Dimensions (without stand) (width x height x depth) [in mm]	611 x 357 x 56
Weight (without stand) [in kg]	5.7
Dimension drawing (PDF)	Dimension drawing (PDF)
Rotatability of the stand [in °]	344
Tiltability forwards/backwards [in °]	5 / 35
Pivot between portrait / landscape	clockwise and anti-clockwise
Height adjustment range [in mm]	176.6
Hole spacing	100 x 100

CERTIFICATION & STANDARDS

Certification	CE, CB, TÜV/GS, TÜV/Ergonomics (including ISO 9241-307), TCO Certified Generation 9, EPEAT 2018 (US), TÜV/Low Blue Light Content, TÜV/Flicker Free, RCM, cTÜVus, FCC-B, CAN ICES-3 (B), TÜV/S, PSE, VCCI-B, EPA ENERGY STAR, RoHS, WEEE, China RoHS, CCC, EAC
EPEAT	EPEAT 2018 Gold (US), EPEAT Climate +

SOFTWARE & ACCESSORIES

Accompanying software and other accessories are available for download	Screen InStyle
Other box contents	USB/signal cable (USB-C - USB-C), Manual via download, Power cord, Quick guide
Accessories	PM200-K (DisplayPort cable to transfer digital video and audio signals), CP200 (USB-C to DisplayPort cable), HH200PR-K (HDMI (High Definition Multimedia Interface) cable), CC100 (USB-C port cable), PP100-K (DisplayPort cable), PP200-K (DisplayPort cable), PCSK-03 (Thin client mount)

WARRANTY

Warranty periode	5 years for unit and LCD module up to 30,000 operating hours, whichever comes first.
Included warranty	Zero pixel defects guarantee; no fully illuminated sub-pixels (sub-pixels ISO 9241-307) for six months from date of purchase.



**Experience the
EV2781 in AR now!**

Find your EIZO contact:
EIZO Europe GmbH
Belgrader Straße 2
41069 Mönchengladbach
Phone: +49 2161 8210-0
www.eizo.eu

All product names are trademarks or registered trademarks of EIZO Corporation in Japan and other countries or their respective companies. Copyright © 2024 EIZO Europe GmbH, Belgrader Str. 2, 41069 Mönchengladbach, Germany. All rights, errors and modifications reserved. Latest update: 08.09.2024